

Split System Air Conditioner

Model:

FAC-12OFTC52

FAC-12INTC52

FAC-18INTC52

FAC-12INTC-52G

FAC-18INTC-52G

We thank you for the trust you have placed in us when purchasing the FOX air conditioner. Please carefully read this manual before using the device to familiarize yourself with the product, its usage instructions, safety measures, and to ensure better and higher-quality performance, as well as a longer lifespan of the device through proper use.

EN

CONTENTS

SAFETY PRECAUTIONS	1
NAMES OF PARTS	4
INDOOR UNIT DISPLAY	5
EMERGENCY FUNCTION & AUTO-RESTART FUNCTION	6
REMOTE CONTROLLER	7
OPERATING INSTRUCTIONS	11
PROTECTION	16
INSTALLATION MANUAL.....	17
MAINTENANCE	26
TROUBLESHOOTING	27

In line with the company's policy of continual product improvement, the aesthetic and dimensional characteristics, technical data and accessories of this appliance may be changed without notice.

SAFETY RULES AND RECOMMENDATIONS FOR THE INSTALLER

- ⚠ Read this guide before installing and using the appliance.**
- ⚠ During the installation of the indoor and outdoor units the access to the working area should be forbidden to children. Unforeseeable accidents could happen.**
- ⚠ Make sure that the base of the outdoor unit is firmly fixed.**
- ⚠ Check that air cannot enter the refrigerant system and check for refrigerant leaks when moving the air conditioner.**
- ⚠ Carry out a test cycle after installing the air conditioner and record the operating data.**
- ⚠ The ratings of the fuse installed in the built incontrol unit are T 5A / 250V .**
- ⚠ The user must protect the indoor unit with a fuse of suitable capacity for the maximum input current or with another overload protection device.**
- ⚠ Ensure that the mains voltage corresponds to that stamped on the rating plate. Keep the switch or power plug clean. Insert the power plug correctly and firmly into the socket, thereby avoiding the risk of electric shock or fire due to insufficient contact.**
- ⚠ Check that the socket is suitable for the plug , otherwise have the socket changed.**
- ⚠ The appliance must be fitted with means for disconnection from the supply mains having a contact separation in all poles that provide full disconnection under overvoltage category III conditions, and these means must be incorporated in the fixed wiring in accordance with the wiring rules.**
- ⚠ The air conditioner must be installed by professional or qualified persons.**

- ⚠ Do not install the appliance at a distance of less than 50 cm from inflammable substances (alcohol, etc.) Or from pressurised containers (e.g. spray cans).**
- ⚠ If the appliance is used in areas without the possibility of ventilation, precautions must be taken to prevent any leaks of refrigerant gas from remaining in the environment and creating a danger of fire**
- ⚠ The packaging materials are recyclable and should be disposed of in the separate waste bins .Take the air conditioner at the end of its useful life to a special waste collection centre for disposal.**
- ⚠ Only use the air conditioner as instructed in this booklet. These instructions are not intended to cover every possible condition and situation . As with any electrical household appliance , common sense and caution are therefore always recommended for installation, operation and maintenance.**
- ⚠ The appliance must be installed in accordance with applicable national regulations.**
- ⚠ Before accessing the terminals , all the power circuits must be disconnected from the power supply.**
- ⚠ The appliance shall be installed in accordance with national wiring regulations.**
- ⚠ This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.**

SAFETY RULES AND RECOMMENDATIONS FOR THE USER

- ⚠ Do not try to install the conditioner alone; always contact specialized technical personnel.**
- ⚠ Cleaning and maintenance must be carried out by specialised technical personnel. In any case disconnect the appliance from the mains electricity supply before carrying out any cleaning or maintenance.**
- ⚠ Ensure that the mains voltage corresponds to that stamped on the rating plate. Keep the switch or power plug clean. Insert the power plug correctly and firmly into the socket , thereby avoiding the risk of electric shock or fire due to insufficient contact.**
- ⚠ Do not pull out the plug to switch off the appliance when it is in operation, since this could create a spark and cause a fire, etc.**
- ⚠ This appliance has been made for air conditioning domestic environments and must not be used for any other purpose , such as for drying clothes, cooling food, etc.**
- ⚠ The packaging materials are recyclable and should be disposed of in the sparate waste bins . Take the air conditioner at the end of its useful life to a special waste collection centre for disposal.**
- ⚠ Always use the appliance with the air filter mounted . The use of the conditioner without air filter could cause an excessive accumulation of dust or waste on the inner parts of the device with possible subsequent failures.**
- ⚠ The user is responsible for having the appliance installed by a qualified technician , who must check that it is earthed in accordance with current legislation and insert a thermomagnetic circuit breaker.**
- ⚠ The batteries in remote controller must be recycled or disposed of properly.
Disposal of Scrap Batteries --- Please discard the batteries as sorted municipal waste at the accessible collection point.**

- ⚠ Never remain directly exposed to the flow of cold air for a long time. The direct and prolonged exposition to cold air could be dangerous for your health .Particular care should be taken in the rooms where there are children , old or sick people.**
- ⚠ If the appliance gives off smoke or there is a smell of burning, immediately cut off the power supply and contact the Service Centre.**
- ⚠ The prolonged use of the device in such conditions could cause fire or electrocution.**
- ⚠ Have repairs carried out only by an authorised Service Centre of the manufacturer . Incorrect repair could expose the user to the risk of electric shock, etc.**
- ⚠ Unhook the automatic switch if you foresee not to use the device for a long time.
The airflow direction must be properly adjusted.**
- ⚠ The flaps must be directed downwards in the heating mode and upwards in the cooling mode.**
- ⚠ Only use the air conditioner as instructed in this booklet.These instructions are not intended to cover every possible condition and situation. As with any electrical household appliance, common sense and caution are therefore always recommended for installation , operation and maintenance.**
- ⚠ Ensure that the appliance is disconnected from the power supply when it will remain inoperative for a long period and before carrying out any cleaning or maintenance.**
- ⚠ Selecting the most suitable temperature can prevent damage to the appliance.**

SAFETY RULES AND PROHIBITIONS


- Do not bend , tug or compress the power cord since this could damage it. Electrical shocks or fire are probably due to a damaged power cord. Specialised technical personnel only must replace a damaged power cord.
- Do not use extensions or gang modules.
- Do not touch the appliance when barefoot or parts of the body are wet or damp.
- Do not obstruct the air inlet or outlet of the indoor or the outdoor unit.
The obstruction of these openings causes a reduction in the operative efficiency of the conditioner with possible consequent failures or damages.
- In no way alter the characteristics of the appliance.
- Do not install the appliance in environments where the air could contain gas , oil or sulphur or near sources of heat.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not climb onto or place any heavy or hot objects on top of the appliance.
- Do not leave windows or doors open for long when the air conditioner is operating.
- Do not direct the airflow onto plants or animals.
- A long direct exposition to the flow of cold air of the conditioner could have negative effects on plants and animals.
- Do not put the conditioner in contact with water.
The electrical insulation could be damaged and thus causing electrocution.
- Do not climb onto or place any objects on the outdoor unit
- Never insert a stick or similar object into the appliance. It could cause injury.
- Children should be supervised to ensure that they do not play with the appliance. If the supply cord is damaged, it must be replaced by the manufacturer,its service agent or similarly qualified persons in order to avoid a hazard.

NAMES OF PARTS

INDOOR UNIT

No.	Description
1	Front panel
2	Air filter
3	Optional filter (if installed)
4	LED Display
5	Signal receiver
6	Terminal block cover
7	Ionizer generator(if installed)
8	Deflectors
9	Emergency button
10	Indoor unit rating label (Stick position optional)
11	Airflow direction louver
12	Remote controller


INDOOR UNIT



OUTDOOR UNIT







No.	Description
13	Air outlet grille
14	Outdoor unit rating label
15	Terminal block cover
16	gas valve
17	liquid valve

OUTDOOR UNIT



Note: the above figures are only intended to be a simple diagram of the appliance and may not correspond to the appearance of the units that have been purchased.

INDOOR UNIT DISPLAY



No.	Led		Function
1	POWER		This symbol appears when the unit is power on
2	SLEEP		SLEEP mode
3	Temperature display (if present) /Error code	88	(1) Lights up during Timer operation when the air conditioner is operational (2) Displays the malfunction code when fault occurs.
4	TIMER		Lights up during Timer operation.
5	RUN		The symbol appears when the unit is turned on, and disappear when the unit is turned off.

The shape and position of switches and indicators may be different according to the model, but their function is the same.


EMERGENCY FUNCTION & AUTO-RESTART FUNCTION

AUTO-RESTART FUNCTION

The appliance is preset auto - restart function by manufacturer. In case of a sudden power failure, the module memorizes the setting conditions before the power failure. when the power restores, the unit restarts automatically with all the previous settings preserved by the memory function.

To deactivate the AUTO-RESTART function ,proceed as follows:

1. Switch the air conditioner off and plug it off.
 2. Press the emergency button meanwhile plug it in.
 3. Keep pressing the emergency button for more than 10 seconds until you hear four short beeps from the unit. The AUTO-RESTART function is deactivate.
- To activate the AUTO - RESTART function , follow the same procedure until you hear three short beeps from the unit.




EMERGENCY FUNCTION

If the remote controller fails to work or maintenance necessary, proceed as follows:

Open and lift the front panel up to an angleto reach the emergency button.

1. One press of the emergency button(one beep) will lead to the forced COOLING operation
 2. Two press of the emergency button within 3 sec (two beeps) will lead to the forced HEATING operation.
 3. To switch off the unit , you just need to press the button again (a single long beep) .
4. After 30 minutes in forced operation , the air conditioner will automatically start working in 23°C cooling mode, auto fan speed.

* The FEEL function is described in page 15.



The shape and position of the emergency button may be different according to the model, but their function is the same.

Remark: the external static pressure ofheat pumps is 0 Pa for all models.

NAME OF PARTS

No.	Button	Function
1		To turn on/ off the air conditioner.
2		To select the operating mode: AUTO, COOLING, DRY, FAN, HEATING.
3		To increase the set room temperature, lengthen the time when set TIMER.
4		To decrease the set room temperature, reduce the time when set TIMER.
5		To set the air flow direction up and down.
6		To set the air flow direction left and right(if applicable,optional).
7		Optional functions indicator:Clean/ECO/Timer/Electrical heating
8		To turn on/off the indoor display.
9		To select the fan speed of indoor unit
10		To switch-on/off the I FEEL function.
11		Press and together and hold is to active/deactive the CHILD-LOCK function.


The display and some functions of the remote control may vary according to the model.

The shape and position of buttons and indicators may vary according to the model, but their function is the same.

The unit confirms the correct reception of each button with a beep.

You will hear a beep when you press the button , though the actual model haven't this function, we express our apologies.

REMOTE CONTROL



 You will hear a beep when you press the button  , though the actual model haven't this function, we express our apologies.

REMOTE CONTROL

Remote controller DISPLAY

Meaning of symbols on the liquid crystal display

No.	Symbols	Meaning
1		Signal indicator
2		Clean
3		Fan speed
4		SLEEP function
5		Timer
6		TURBO function
7		Child-Lock
8		Electrical heating
9		Auto Mode
10		Mute function
11		Cooling Mode
12		Display ON/OFF
13		Dry Mode
14		Left-right auto swing
15		Up-down auto swing
16		ECO Mode
17		Temperature/Time indicator
18		Fan only Mode
19		Heating Mode
20		UV lamp
21		I Feel
22		MUTE with the lowest speed
23		Low fan speed
24		Low-Mid fan speed
25		Mid fan speed
26		Mid-High fan speed
27		High fan speed
28		Automatic fan speed
29		Turbo with the highest fan speed

REMOTE CONTROL

Replacement of Batteries


Remove the battery cover plate from the rear of the remote controller, by sliding it in the direction of the arrow.

Install the batteries according the direction (+ and -)shown on the Remote Controller.

Reinstall the battery cover by sliding it into place.

⚠ Use 2 LRO 3 AAA (1.5V) batteries . Do not use rechargeable batteries . Replace the old batteries with new ones of the same type when the display is no longer legible.

Do not dispose batteries as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.




Notes

1.If not use the remote control for a long time, take out the battery.

2.Simultaneously press and hold the \wedge and \vee buttons for more than 1S to activate the child lock, and press again to release it.

Please remove batteries to avoid leakage damage


- ⚠**
1. Direct the remote controller toward the Air conditioner.
 2. Check that there are no objects between the remote control and the Signal receptor in the indoor unit.
 3. Never leave the remote controller exposed to the rays of the sun.
 4. Keep the remote controller at a distance of at least 1m from the television or other electrical appliances.



REMOTE CONTROL

The air sucked by the fan enters from the grill and passes through the filter, then it is cooled/dehumidified or heated through the heat exchanger.

The direction of the air outlet is motorized up and down by flaps, and manually moved right and left by the vertical deflectors, for some models, the vertical deflectors could be controlled by motor as well.



Controlling air flow direction

1. To change the vertical airflow direction:

Press to activate the horizontal flaps to swing from up to down automatically and shows on remote controller display. Press again to stop the swing movement and keep the current angle.

2. To change the horizontal airflow direction:



Manually change the vertical deflectors direction when stop horizontal flaps movements.

Press is intend to enable the vertical deflectors to swing from left to right. Press again to stop the swing movement and keep the current angle.

(But for this model, there is no any function only hear a beep and shows on the remote controller display when press this button)

Never adjust "Horizontal flaps" manually, it may not close completely when you turn off the air conditioner.

Never poke fingers, sticks or other objects in the air inlet or outlet vents. Such accidental contact with live parts might cause unforeseeable damage or injury.



REMOTE CONTROL

COOLING MODE



The cooling function allows the air conditioner to cool the room and reduce Air humidity at the same time.

To activate the cooling function (COOL), press the button until the symbol appears on the display.

With the button or set a temperature lower than that of the room.

HEATING MODE




The heating function allows the air conditioner to heat the room.

To activate the heating function (HEAT), press the button until the symbol appears on the display.

With the button or set a temperature higher than that of the room.



In HEATING operation, the appliance can automatically activate a defrost cycle, which is essential to clean the frost on the condenser so as to recover its heat exchange function. This procedure usually lasts for 2-10 minutes. During defrosting, indoor unit fan stop operation. After defrosting, it resumes to HEATING mode automatically.



DRY MODE



This function reduces the humidity of the air to make the room more comfortable.

To set the DRY mode, Press until appears in the display. An automatic function of pre-setting is activated.


REMOTE CONTROL

FAN MODE(Not FAN button)



Fan mode, air ventilation only.

To set the FAN mode, Press until appears in the display. An automatic function of pre-setting is activated.




AUTO MODE



Automatic mode.

To set the AUTO mode, press until appears on the display.
In AUTO mode the run mode will be set automatically according to the room temperature.



DISPLAY function (Indoor display)



Switch ON/OFF the LED display on panel.

Press button to switch off the LED display on the panel. Press again to switch on the LED display.

REMOTE CONTROL

ECO function




This function allows the appliance sets the operation automatically to save energy.

Only in Heating or Cooling model, Press the button, select the ECO by pressing the button or until symbol ECO on the panel. Then press button again. and the appliance will run in ECO mode.

NOTE:

The ECO function is available on both COOLING and HEATING modes.



SLEEP function



Pre-setting automatic operating program.

Press the button, then press and until mark flashing, press to confirm the choosing and activate the SLEEP function.
Do again as above to cancel it.

NOTE:

The SLEEP function is available in both COOLING and HEATING modes.

After 10 hours running in sleep mode, the air conditioner will change to the previously set mode.

REMOTE CONTROL

Self-clean function (Optional)



Shows "AC" on indoor display during this function process.

Switch off the air conditioner by pressing .


Press the button, symbol is flashing; Press again activate the CLEAN function, and AC appears on the it again to deactivate this function.

NOTE:

1. We suggest operate this function as the following ambient condition to avoid certain safety protection features.

Indoor unit	Temp<30°C
Outdoor unit	5°C<Temp<30°C

2. We suggest operate this function per 3 months.




Controlling fan speed



Select the fan speed on AUTO/FAN/ COOLING/HEATING modes.

Press button to select the fan speed AUTO/MUTE/LOW/ LOW-MID/MID/MID-HIGH/HIGH/TURBO.

	MUTE with the lowest fan speed
	Low fan speed
	Low-Mid fan speed
	Mid fan speed
	Mid-High fan speed
	High fan speed
	Automatic fan speed
	Turbo with the highest fan speed



REMOTE CONTROL

TIMER function

TIMER

To automatically switch on/off the air conditioner.

When the unit is switch-off, you can set the TIMER ON.

1.Press the  button,select the  by pressing the button \wedge or \vee until symbol  on the panel.Then press  button again.

2.Set the desired Mode/Fan speed/temperature then press the  button.

3.The digital like 0.5H is flashing, press \wedge or \vee to set the desired time between 0.5h to 24h.Then press the  button to conform.

4.CANCEL it by press  button.

When the unit is ON, you can set the TIMER OFF.

1.Press the  button,select the  by pressing the button \wedge or \vee until symbol  on the panel.Then press  button again.

2.Press \wedge or \vee to button to set desired Timer-on time between 0.5h to 24h.Then press the  button to conform.



3.CANCEL it by press  button.

To cancel the Timer, press the TIMER button  two times.



Note:

All programming should be operated within 5 seconds, otherwise the setting will be cancelled.



I FEEL function (Optional)

I FEEL

Press **I FEEL** button to active the function, the  will appear on the remote display.

Do it again to deactivate this function.

This function enables the remote control to measure the temperature at its current location, and send this signal to the air conditioner to optimize the temperature around you and ensure the comfort.

It will automatically deactivate 2 hours later.

PROTECTION

The air conditioner is programmed for comfortable and suitable living conditions, if it is used in abnormal condition as below, certain safety protection features might come into effect.

For T1 Climate condition models:

No.	MODE	Ambient temperature
1	Heating	Outdoor temperature is over 24°C
		Outdoor temperature is below -7°C
		Room temperature is over 27°C
2	Cooling	Outdoor temperature is over 43°C
		Room temperature is below 21 °C
3	Dry	Room temperature is below 18° C

For Tropical (T3) Climate condition models:

No.	MODE	Ambient temperature
1	Heating	Outdoor temperature is over 24°C
		Outdoor temperature is below -7°C
		Room temperature is over 27°C
2	Cooling	Outdoor temperature is over 52°C
		Room temperature is below 21 °C
3	Dry	Room temperature is below 18° C

 *The unit does not operate immediately if it is turned on after being turned off or after changing the mode during operation. this is a normal self-protection action, you need wait for about 3 minutes.*


 *The capacity and efficiency are according to the test conducted at full-load operation*.*

**The highest speed of indoor fan motor and the maximum open angle of the flaps and deflectors are requested.*

INSTALLATION MANUAL---Selecting the Installation Place

INDOOR UNIT


- Install the indoor unit on a strong wall that is not subject to vibrations.
- The inlet and outlet ports should not be obstructed: the air should be able to blow all over the room.
- Do not install the unit near a source of heat, steam, or flammable gas.
- Install the unit near an electric socket or private circuit.
- Do not install the unit where it will be exposed to direct sunlight.
- Select a site where the condensed water can be easily drained out, and where it is easily connected to outdoor unit.
- Check the machine operation regularly and reserve the necessary spaces as shown in the picture.
- Select a place where the filter can be easily taken out.




OUTDOOR UNIT

- Do not install the outdoor unit near sources of heat, steam or flammable gas.
- Do not install the unit in too windy or dusty places.
- Do not install the unit where people often pass. Select a place where the air discharge and operating sound will not disturb the neighbours.
- Avoid installing the unit where it will be exposed to direct sunlight (otherwise use a protection, if necessary, that should not interfere with the air flow).
- Reserve the spaces as shown in the picture for the air to circulate freely.
- Install the outdoor unit in a safe and solid place.
- If the outdoor unit is subject to vibration, place rubber gaskets onto the feet of the unit..

minimum space to be reserved (mm) showing in the picture



Installation Diagram



The purchaser must ensure that the person and/or company who is to install, maintain or repair this air conditioner has qualifications and experience in refrigerant products.

INSTALLATION MANUAL---Installation of the Indoor unit


Before starting installation, decide on the position of the indoor and outdoor units, taking into account the minimum space reserved around the units

- ⚠ Do not install your air conditioner in a wet room such as a bathroom or laundry etc
- ⚠ The installation site should be 250cm or more above the floor.

To install, proceed as follows:

Installation of the mounting plate

- 1 Always mount the rear panel horizontally and vertically
- 2 Drill 32 mm deep holes in the wall to fix the plate;
- 3 Insert the plastic anchors into the hole;
- 4 Fix the rear panel on the wall with provided tapping screws
- 5 Be sure that the rear panel has been fixed firmly enough to withstand the weight




Note : The shape of the mounting plate may be different from the one above, but installation method is similar .

Drilling a hole in the wall for the piping

- 1 Make the piping hole ($\Phi 55$) in the wall at a slight downward slant to the outdoor side.
- 2 Insert the piping-hole sleeve into the hole to prevent the connection piping and wiring from being damaged when passing through the hole.

- ⚠ The hole must slope downwards towards the exterior

Note : Keep the drain pipe down towards the direction of the wall hole, otherwise leakage may occur.



Electrical connections--Indoor unit

- 1 Open the front panel.
- 2 Take off the cover as indicated in the picture (by removing a screw or breaking the hooks).
- 3 For the electrical connections, see the circuit diagram on the right part of the unit under the front panel.
- 4 Connect the cable wires to the screw terminals by following the numbering ,Use wire size suitable to the electric power input (see name plate on the unit) and according to all current national safety code requirements.


- ⚠ The cable connecting the outdoor and indoor units must be suitable for outdoor use.

- ⚠ The plug must be accessible also after the appliance has been installed so that it can be pulled out if necessary.

- ⚠ An efficient earth connection must be ensured.

- ⚠ If the power cable is damaged, it must be replaced by an authorised Service Centre.

Note:Optional the wires can be connected to the main PCB of indoor unit by manufacturer according to the model without terminal block.





INSTALLATION MANUAL---Installation of the Indoor unit

Refrigerant piping connection

The piping can be run in the 3 directions indicated by numbers in the picture . When the piping is run in direction 1 or 3, cut a notch along the groove on the side of the indoor unit with a cutter.

Run the piping in the direction of the wall hole and bind the copper pipes , the drain pipe and the power cables together with the tape with the drain pipe at the bottom, so that water can flow freely.


- Do not remove the cap from the pipe until connecting it, to avoid dampness or dirt from entering.
- If the pipe is bent or pulled too often , it will become stiff . Do not bend the pipe more than three times at one point.
- When extending the rolled pipe, straighten the pipe by unwinding it gently as shown in the picture.




Extending the rolled pipe




torque wrench



YES



NO



NO

Connections to the indoor unit

1. Remove the indoor unit pipe cap (check that there is no debris inside).
2. Insert the fare nut and create a flange at the extreme end of the connection pipe.
3. Tighten the connections by using two wrenches working in opposite directions

Indoor unit condensed water drainage

The indoor unit condensed water drainage is fundamental for the success of the installation.


1. Place the drain hose below the piping, taking care not to create siphons.
 2. The drain hose must slant downwards to aid drainage.
 3. Do not bend the drain hose or leave it protruding or twisted and do not put the end of it in water . If an extension is connected to the drain hose , ensure that it is lagged when it passes into the indoor unit.
 4. If the piping is installed to the right, the pipes, power cable and drain hose must be lagged and secured onto the rear of the unit with a pipe connection.
- 1) Insert the pipe connection into the relative slot.
 - 2) Press to join the pipe connection to the base.

INSTALLATION MANUAL---Installation of the Indoor unit

INSTALLATION OF THE INDOOR UNIT

After having connected the pipe according to the instructions, install the connection cables. Now install the drain pipe. After connection, lag the pipe, cables and drain pipe with the insulating material.

1. Arrange the pipes ,cables and drain hose well.
2. Lag the pipe joints with insulating material , securing it with vinyl tape.
3. Run the bound pipe , Cables and drain pipe through the wall hole and mount the indoor unit onto the upper part of the mounting plate securely.
4. Press and push the lower part of the indoor unit tightly against the mounting plate




INSTALLATION MANUAL---Installation of the outdoor unit

- The outdoor unit should be installed on a solid wall and fastened securely.
- The following procedure must be observed before connecting the pipes and connecting cables : decide which is the best position on the wall and leave enough space to be able to carry out maintenance easily.
- Fasten the support to the wall using screw anchors which are particularly suited to the type of wall;
- Use a larger quantity of screw anchors than normally required for the weight they have to bear to avoid vibration during operation and remain fastened in the same position for years without the screws becoming loose.
- The unit must be installed following the national regulations.

Outdoor unit condensed water drainage (only for heat pump models)

The condensed water and the ice formed in the outdoor unit during heating operation can be drained away through the drain pipe


1. Fasten the drain port in the 25mm hole placed in the part of the unit as shown in the picture.
2. Connect the drain port and the drain pipe.
Pay attention that water is drained in a suitable place.



INSTALLATION MANUAL---Installation of the outdoor unit

ELECTRICAL CONNECTIONS

1. Remove the handle on the right side plate of outdoor unit.
2. Connect the power connection cord to the terminal board.
Wiring should fit that of indoor unit.
3. Fix the power connection cord with wire clamp.
4. Confirm if the wire has been fixed properly.
5. An efficient earth connection must be ensured.
6. Recover the handle.




CONNECTING THE PIPES

Screw the flare nuts to the outdoor unit coupling with the same tightening procedures described for the indoor unit.


To avoid leakage, pay attention to the following points:

1. Tighten the flare nuts using two wrenches. Pay attention not to damage the pipes.
2. If the tightening torque is not sufficient, there will probably be some leakage. With excessive tightening torque there will also be some leakage, as the flange could be damaged.
3. The surest system consists in tightening the connection by using a fix wrench and a torque wrench: in this case use the table on page 23.



BLEEDING

Air and humidity left inside the refrigerant circuit can cause compressor malfunction. After having connected the indoor and outdoor units, bleed the air and humidity from the refrigerant circuit by using a vacuum pump.




INSTALLATION MANUAL---Installation of the outdoor unit

BLEEDING

The air and humidity left inside the refrigerant circulation can cause compressor malfunction. After having connected the indoor and outdoor units, bleed the air and humidity from the refrigerant circulation using a vacuum pump.

- (1) Unscrew and remove the caps from the 2-way and 3-way valves.
- (2) Unscrew and remove the cap from the service port.
- (3) Connect the vacuum pump hose to the service port.
- (4) Operate the vacuum pump for 10 - 15 minutes until an absolute vacuum of 10 mm Hg has been reached.
- (5) With the vacuum pump still in operation, close the low-pressure knob on the vacuum pump coupling. Stop the vacuum pump.
- (6) Open the 2-way valve by 1/4 turn and then close it after 10 seconds. Check all the joints for leaks using liquid soap or an electronic leak device.
- (7) Turn the body of the 2-way and 3-way valves. Disconnect the vacuum pump hose.
- (8) Replace and tighten all the caps on the valves.



INSTALLATION MANUAL--- operation test

1. Wind insulating covering around the joints of the indoor unit and fix it with insulating tape.
2. Fix the exceeding part of the signal cable to the piping or to the outdoor unit.
3. Fix the piping to the wall (after having coated it with insulating tape) using clamps or insert them into plastic slots.
4. Seal the hole in the wall through which the piping is passed so that no air or water can fill.


Indoor unit test

- Do the ON/OFF and FAN operate normally?
- Does the MODE operate normally?
- Do the set point and TIMER function properly?
- Does each lamp light normally?
- Do the flap for air flow direction operate normally?
- Is the condensed water drained regularly?

Outdoor unit test

- Is there any abnormal noise or vibration during operation?
- Could the noise, the air flow or the condensed water drainage disturb the neighbours?
- Is there any coolant leakage?

Note: the electronic controller allows the compressor to start only three minutes after voltage has reached the system.



INSTALLATION MANUAL---Information for the installer

FIXED-SPEED TYPE MODEL capacity (Btu/h)	5k	7k	9k	12k	15/18k	22/24k	28/30k/36k
Liquid pipe diameter	1/4 " (Φ 6)	1/4 " (Φ 6)	1/4 " (Φ 6)	1/4 " (Φ 6)	1/4 " (Φ 6)	3/8 " (Φ 9.52)	3/8 " (Φ 9.52)
Gas pipe diameter	3/8 " (Φ 9.52)	3/8 " (Φ 9.52)	3/8 " (Φ 9.52)	1/2 " (Φ 12)	1/2 " (Φ 12)	5/8 " (Φ 15.88)	5/8 " (Φ 15.88)
Lenght of pipe with standard charge	3m	3m	3m	3m	4m	4m	4m
Maximum distance between indoor and outdoor unit	15m	15m	15m	15m	15m	15m	15m
Additional refrigerant charge	20g/m	20g/m	20g/m	20g/m	30g/m	30g/m	30g/m
Max. diff. in level between indoor and outdoor unit	5m	5m	5m	5m	5m	5m	5m
Type of refrigerant(1)	R22	R22	R22	R22	R22	R22	R22

FIXED-SPEED TYPE MODEL capacity (Btu/h)	7k	9k	12k	15/18k	22/24k	28/30k/36k
Liquid pipe diameter	1/4 " (Φ 6)	1/4 " (Φ 6)	1/4 " (Φ 6)	1/4 " (Φ 6)	3/8 " (Φ 9.52)	3/8 " (Φ 9.52)
Gas pipe diameter	3/8 " (Φ 9.52)	3/8 " (Φ 9.52)	3/8 " (Φ 9.52)	1/2 " (Φ 12)	5/8 " (Φ 15.88)	5/8 " (Φ 15.88)
Lenght of pipe with standard charge	3m	3m	3m	4m	4m	4m
Maximum distance between indoor and outdoor unit	15m	15m	15m	15m	15m	15m
Additional refrigerant charge	20g/m	20g/m	20g/m	30g/m	30g/m	30g/m
Max. diff. in level between indoor and outdoor unit	5m	5m	5m	5m	5m	5m
Type of refrigerant(1)	R410A	R410A	R410A	R410A	R410A	R410A

INVERTER TYPE MODEL capacity (Btu/h)	9k	12k		15/18k	22/24k
Liquid pipe diameter	1/4 " (Φ 6)		1/4 " (Φ 6)	1/4 " (Φ 6)	3/8 " (Φ 9.52)
Gas pipe diameter	3/8 " (Φ 9.52)		3/8 " (Φ 9.52)	1/2 " (Φ 12)	5/8 " (Φ 15.88)
Lenght of pipe with standard charge	3m		3m	4m	4m
Maximum distance between indoor and outdoor unit	15m		15m	15m	15m
Additional refrigerant charge	20g/m		20g/m	20g/m	30g/m
Max. diff. in level between indoor and outdoor unit	5m		5m	5m	5m
Type of refrigerant(1)	R410A		R410A	R410A	R410A

(1) Refer to the data rating label sticked on the outdoor unit.

TIGHTENING TORQUE FOR PROTECTION CAPS AND FLANGE CONNECTION

PIPE	TIGHTENING TORQUE [N x m]	CORRESPONDING STRESS (using a 20 cm wrench)		TIGHTENING TORQUE [N x m]
1/4 " (Φ 6)	15 - 20	wrist strength	Service port nut	7 - 9
3/8 " (Φ 9.52)	31 - 35	arm strength	Protection caps	25 - 30
1/2 " (Φ 12)	35 - 45	arm strength		
5/8 " (Φ 15.88)	75 - 80	arm strength		



INSTALLATION MANUAL---Information for the installer

WIRING DIAGRAM

For different models, the wiring diagram may be different. Please refer to the wiring diagrams pasted on the indoor unit and outdoor unit respectively.

On indoor unit, the wiring diagram is pasted under the front panel;

On outdoor unit, the wiring diagram is pasted on the backside of the outdoor handle cover.



Note: For some models the wires has been connected to the main PCB of indoor unit by manufacturer without terminal block.

INSTALLATION MANUAL---Information for the installer

CABLE WIRES SPECIFICATION

MODEL	capacity (Btu/h)	5k	7k	9k	12k	15/18k	22/24k	28/30k/36k
		sectional area						
Power supply cable	N	1.0mm ² AWG18	1.0mm ² AWG18	1.0mm ² AWG18	1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.5mm ² AWG16	2.5mm ² AWG14 H05RN-F	4.0mm ² AWG12
	L	1.0mm ² AWG18	1.0mm ² AWG18	1.0mm ² AWG18	1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.5mm ² AWG16	2.5mm ² AWG14 H05RN-F	4.0mm ² AWG12
	E	1.0mm ² AWG18	1.0mm ² AWG18	1.0mm ² AWG18	1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.5mm ² AWG16	2.5mm ² AWG14 H05RN-F	4.0mm ² AWG12
Connection supply cable	N	1.0mm ²	1.0mm ²	1.0mm ²	1.0mm ² (1.5mm) ³	1.5mm ²	0.75mm ²	0.75mm ²
	L	1.0mm ²	1.0mm ²	1.0mm ²	1.0mm ² (1.5mm) ³	1.5mm ²	0.75mm ²	0.75mm ²
	1	1.0mm ²	1.0mm ²	1.0mm ²	1.0mm ² (1.5mm) ³	1.5mm ²	0.75mm ²	0.75mm ²
	2	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²
	3	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²
	⊕	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²

MODEL	capacity (Btu/h)	INVERTER TYPE			9k	12k	18/22k	24k	
		sectional area							
Power supply cable	N			1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.5mm ² AWG16	2.5mm ² AWG14		
	L			1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.5mm ² AWG16	2.5mm ² AWG14		
	E			1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.5mm ² AWG16	2.5mm ² AWG14		
Connection supply cable	N			1.0mm ² (1.5mm) ³	1.0mm ² (1.5mm) ³	1.5mm ²	0.75mm ²		
	L			1.0mm ² (1.5mm) ³	1.0mm ² (1.5mm) ³	1.5mm ²	0.75mm ²		
	1			1.0mm ² (1.5mm) ³	1.0mm ² (1.5mm) ³	1.5mm ²	0.75mm ²		
	⊕			1.0mm ² (1.5mm) ³	1.0mm ² (1.5mm) ³	1.5mm ²	0.75mm ²		

220V 7K , 9K , 12K 15K , 16K , 18K , 22K , 24K , 30K air conditioner indoor unit fuse parameter is 50T, 3.15A
 110V 7K , 9K 12k air conditioner indoor unit fuse parameter is 50T, 3.15A,
 125V 7K , 9K , 12K air conditioner outdoor unit fuse parameter is 61T, 15A
 250V 18K , 22K , 24K air conditioner outdoor unit fuse parameter is 65TS, 25A

MAINTENANCE

Periodic maintenance is essential for keeping your air conditioner efficient.




Before carrying out any maintenance , disconnect the power supply by taking the plug out from the socket.

INDOOR UNIT

ANTIDUST FILTERS

1. Open the front panel following the direction of the arrow
2. Keeping the front panel raised with one hand, take out the air filter with the other hand
3. Clean the filter with water ; if the filter is soiled with oil,it can be washed with warm water (not exceeding 45°C). Leave to dry in a cool and dry place.
4. Keeping the front panel raised with one hand , insert the air filter with the other hand
5. Close

The electrostatic and the deodorant filter (if installed) cannot be washed or regenerated and must be replaced with new filters after every 6 months.



CLEANING THE HEAT EXCHANGER

1. Open the front panel of the unit and life it till its greatest stroke and then unhooking it from the hinges to make the cleaning easier.
2. Clean the indoor unit using a cloth with the water (not higher than 40°C) and neutral soap . Never use aggressive solvents or detergents.
3. If the outdoor unit is clogged , remove the leaves and the waste and remove the dust with air jet or a bit of water.

END OF SEASON MAINTENANCE

1. Disconnect the automatic switch or the plug.
2. Clean and replace the filters
3. On a sunny day let the conditioner work in ventilation for some hours , so that the inside of the unit can dry completely..

REPLACING THE BATTERIES

When: • There is no confirmation beep heard from the indoor unit.

• The LCD doesn't act.

How: • Take off the cover at back.

• Place the new batteries respecting the symbols + and - .

N.B: Use only new batteries. Remove the batteries from the remote controller when the conditioner is not in operation

WARNING ! Do not throw batteries into common rubbish , they should be disposed of in the special containers situated in the collection points.

TROUBLESHOOTING

MALFUNCTION	POSSIBLE CAUSES
The appliance does not operate	Power failure/plug pulled out
	Damaged indoor/outdoor unit fan motor
	Faulty compressor thermomagnetic circuit breaker
	Faulty protective device or fuses.
	Loose connections or plug pulled out
	It sometimes stops operating to protect the appliance.
	Voltage higher or lower than the voltage range
	Active TIMER-ON function
	Damaged electronic control board
Strange odour	Air filter dirty
Noise of running water	Back flow of liquid in the refrigerant circulation
A fine mist comes from the air outlet	This occurs when the air in the room becomes very cold, for example in the “COOLING” or “DEHUMIDIFYING/DRY” modes.
A strange noise can be heard	This noise is made by the expansion or contraction of the front panel due to variations in temperature and does not indicate a problem.
Insufficient airflow, either hot or cold	Inappropriate temperature setting..
	Air inlet or outlet of indoor or outdoor unit has been blocked.
	Air filter is blocked.
	Fan speed set at minimum.
	Other sources of heat in the room.
	No refrigerant.
The appliance does not respond to commands	Remote control is not near enough to indoor unit.
	Battery in Remote controller may have been exhausted..
	Obstacles between remote control and signal receiver in indoor unit.
The display is off	Active LED function
	Power failure

Switch off the air conditioner immediately and cut off the power supply in the event of:

Strange noises during operation.

Faulty electronic control board

Faulty fuses or switches.

Spraying water or objects inside the appliance.






Overheated cables or plugs.

Very strong smells coming from the appliance.

ERROR SIGNALS ON THE DISPLAY

In case of error, the display on the indoor unit shown the following error codes:

	RUN lamp	Description of the trouble
E1	flashes once	The fault of indoor temperature sensor
E2	flashes twice	The fault of indoor pipe temperature sensor
E6	flashes 6 times	Malfunction of indoor fan motor.



More about the technical specifications of this air conditioner, as well as other FOX Electronics products, can be found at the following website.

www.foxelectronics.rs



Split Sistem Klima Uređaj

Model:

FAC-12OFTC52

FAC-12INTC52

FAC-18INTC52

FAC-12INTC-52G

FAC-18INTC-52G

Zahvaljujemo se na poverenju koje ste nam ukazali prilikom kupovine FOX klima uređaja. Molimo Vas da pre korišćenja uređaja, pažljivo proučite ovo uputstvo kako biste upoznali proizvod, način upotrebe i mere sigurnosti i pravilnim korišćenjem obezbedili bolji i kvalitetniji rad, kao i duži vek trajanja uređaja.

SR

SADRŽAJ

BEZBEDNOSNE MERE	1
DELOVI UREĐAJA	4
PRIKAZ UNUTRAŠNJE JEDINICE	5
FUNKCIJA U HITNIM SLUČAJEVIMA I FUNKCIJA AUTOMATSKOG RESTARTOVANJA UREĐAJA	6
DALJINSKI UPRAVLJAČ	7
UPUTSTVA ZA RUKOVANJE	11
ZAŠTITA	16
UPUTSTVO ZA INSTALACIJU	17
ODRŽAVANJE	26
REŠENJA PROBLEMA	27

U skladu sa politikom kompanije radi kontinuiranog poboljšanja kvaliteta proizvoda, estetskog izgleda i dimenzija, tehnički podaci i dodaci ovog uređaja mogu se promeniti bez prethodne najave.

BEZBEDNOSNA PRAVILA I PREPORUKE ZA INSTALATERA

- ⚠️ Pročitajte ovo uputstvo pre instaliranja i upotrebe uređaja.**
- ⚠️ Tokom ugradnje unutrašnje i spoljne jedinice deci treba zabraniti pristup radnom prostoru. Mogu se dogoditi nepredvidive nezgode.**
- ⚠️ Uverite se da je postolje spoljne jedinice čvrsto postavljeno.**
- ⚠️ Uverite se da vazduh ne može ući u sistem rashladnog sredstva i proverite da li curi rashladno sredstvo prilikom pomeranja klima uređaja.**
- ⚠️ Uradite ciklus testiranja nakon ugradnje klima uređaja i zabeležite podatke o radu.**
- ⚠️ Nazivi osigurača ugrađenih u ugrađenu upravljačku jedinicu su T5A / 250V.**
- ⚠️ Korisnik mora zaštititi unutrašnju jedinicu osiguračem odgovarajućeg kapaciteta za maksimalnu ulaznu struju ili drugim uredajem za zaštitu od preopterećenja.**
- ⚠️ Uverite se da mrežni napon odgovara naponu odštampanom na pločici sa podacima. Prekidač ili utikač održavajte čistim. Utaknite ispravno i čvrsto utikač u utičnicu, izbegavajući rizik od strujnog udara ili požara usled nedovoljnog kontakta.**
- ⚠️ Pроверите da li je utičnica pogodna za utikač, u suprotnom promenite utičnicu.**
- ⚠️ Uredaj mora biti opremljen sredstvima za odvajanje od dovodne mreže koja imaju razdvajanje kontakata na svim polovima koji omogućavaju potpuno odvajanje u uslovima prenapona kategorije III, a ta sredstva moraju biti ugrađena u fiksno ožičenje u skladu sa pravilima ožičenja.**
- ⚠️ Klima uređaj moraju instalirati stručne ili kvalifikovane osobe.**
- ⚠️ Ne postavljajte uređaj na rastojanju manjem od 50 cm od zapaljivih supstanci (alkohol, itd.) ili od posuda pod pritiskom (npr. limenke za prskanje).**
- ⚠️ Ukoliko se uređaj koristi u prostorijama bez mogućnosti ventilacije, moraju se preduzeti mere predostrožnosti kako bi se sprečilo da curenje rashladnog gasa ostane u okruženju i stvoriti opasnost od požara.**
- ⚠️ Materijali za pakovanje mogu se reciklirati i odlagati u odvojene kontejnere za otpad. Na kraju svog korisnog veka odnesite klima uredaj na odlaganje u poseban centar za sakupljanje otpada.**
- ⚠️ Koristite klima uređaj samo onako kako je navedeno u ovom uputstvu. Ova uputstva nisu namenjena pokrivanju svih mogućih uslova i situacija, kao i kod bilo kog drugog električnog uređaja za domaćinstvo, zato se za ugradnju, rad i održavanje uvek preporučuju zdrav razum i oprez.**
- ⚠️ Uredaj mora biti instaliran u skladu sa važećim nacionalnim propisima.**
- ⚠️ Pre pristupa terminalima, sva strujna kola moraju biti isključena iz napajanja.**
- ⚠️ Uredaj mora biti instaliran u skladu sa nacionalnim propisima o ožičenju.**
- ⚠️ Ovaj uređaj mogu da koriste deca uzrasta od 8 godina i više i osobe smanjene fizičke, senzorne ili mentalne sposobnosti ili sa nedostatkom iskustva i znanja ako su dobili nadzor ili uputstva u vezi sa upotrebom uređaja na bezbedan način i ako razumeju uključene opasnosti. Deca se ne smeju igrati uređajem. Čišćenje i održavanje korisnika ne smeju vršiti deca bez nadzora.**

BEZBEDNOSNA PRAVILA I PREPORUKE ZA INSTALATERA

- ⚠ Ne pokušavajte da sami instalirate uređaj, uvek kontaktirajte specijalizovano tehničko osoblje.
- ⚠ Čišćenje i održavanje mora obavljati specijalizovano tehničko osoblje. U svakom slučaju isključite uređaj iz električne mreže pre bilo kakvog čišćenja ili održavanja.
- ⚠ Uverite se da mrežni napon odgovara naponu odštampanom na pločici sa podacima. Prekidač ili utikač održavajte čistim. Uključite ispravno i čvrsto utikač u utičnicu, izbegavajući rizik od strujnog udara ili požara usled nedovoljnog kontakta.
- ⚠ Ne izvlačite utikač da biste isključili uređaj dok radi, jer to može stvoriti iskru i izazvati požar itd.
- ⚠ Ovaj uređaj je napravljen za klimatizaciju u kućnim uslovima i ne sme se koristiti u bilo koje druge svrhe, kao što je sušenje odeće, hlađenje hrane itd.
- ⚠ Materijali za pakovanje mogu se reciklirati i odlagati u odvojene kontejnere za otpad. Na kraju korisnog veka uređaja, odnesite klima uređaj na odlaganje u poseban centar za sakupljanje otpada.
- ⚠ Uredaj uvek koristite sa montiranim vazdušnim filterom. Upotreba uređaja bez vazdušnog filtera može prouzrokovati prekomerno nakupljanje prašine ili otpada na unutrašnjim delovima uređaja sa mogućim naknadnim kvarovima.
- ⚠ Korisnik je odgovoran za to da uređaj instalira kvalifikovani tehničar, koji mora da proveri da li je uzemljen u skladu sa važećom zakonskom regulativom i da ubaci termo magnetni prekidač.
- ⚠ Baterije u daljinskom upravljaču moraju se reciklirati ili pravilno održavati. Odlaganje istrošenih baterija --- Bacite baterije kao sortirani komunalni otpad na dostupnom mestu za sakupljanje.

- ⚠ Nikada nemojte dugo ostajati izloženi izlazu hladnog vazduha. Direktno i dugotrajno izlaganje hladnom vazduhu može biti opasno po vaše zdravlje. Naročito treba biti pažljiv u prostorijama u kojima su deca, stari ili bolesni ljudi.
- ⚠ Ukoliko uređaj ispušta dim ili postoj miris paljevine, odmah isključite napajanje i kontaktirajte servisni centar.
- ⚠ Duža upotreba uređaja u takvim uslovima može prouzrokovati požar ili strujni udar.
- ⚠ Opravke mora da obavlja samo ovlašćeni servisni centar proizvođača. Nepravilna popravka može izložiti korisnika riziku od električnog udara itd.
- ⚠ Isključite automatski prekidač ako znate da uređaj nećete koristiti duže vreme. Smer protoka vazduha mora biti pravilno podešen.
- ⚠ Krilca moraju biti usmerena prema dole u režimu grejanja i prema gore u režimu hlađenja.
- ⚠ Koristite klima uređaj samo onako kako je navedeno u ovim uputstvima. Ova uputstva nisu u obavezi da pokriju sva moguća stanja i situacije kao i kod ostalih električnih uređaja za domaćinstvo, zato se za ugradnju, rad i održavanje uvek preporučuju zdrav razum i oprez.
- ⚠ Uverite se da je uređaj isključen iz napajanja kada će dugo raditi i pre čišćenja ili održavanja.
- ⚠ Izborom najprikladnije temperature možete sprečiti oštećenje uređaja.

BEZBEDNOSNA PRAVILA I ZABRANE

- Nemojte savijati, vući ili pritiskati kabl za napajanje jer bi to moglo da ga ošteći. Strujni udari ili požar su verovatno posledica oštećenja kabla za napajanje. Samo specijalizovano tehničko osoblje mora zameniti oštećeni kabl za napajanje.
- Nemojte koristiti produžne kablove ili utičnice s prekidačima.
- Ne dodirujte uređaj kada ste bosi ili su delovi vašeg tela mokri ili vlažni.
- Ne ometajte ulaz ili izlaz vazduha unutrašnje ili spoljne jedinice. Prepreka na ovim otvorima uzrokuje smanjenje operativne efikasnosti uređaja sa mogućim kvarovima ili oštećenjima.
- Ni na koji način ne menjajte karakteristike uređaja.
- Ne postavljajte uređaj u okruženjima u kojima vazduh može sadržati gas, ulje ili sumpor ili u blizini izvora topote.
- Ovaj uređaj nije namenjen za upotrebu osobama (uključujući decu) sa smanjenim fizičkim, senzornim ili mentalnim sposobnostima ili sa nedostatkom iskustva i znanja, osim ako su pod nadzorom osobe odgovorne za njihovu bezbednost ili su im data uputstva u vezi sa bezbednom upotreboom uređaja.


- Nemojte se penjati na unutrašnju jedinicu uređaja niti stavljati teške ili vruće predmete na nju.
- Ne ostavljajte prozore ili vrata dugo otvorena tokom rada klima uređaja.
- Ne usmeravajte protok vazduha na biljke ili životinje.
- Dugo direktno izlaganje strujanju hladnog vazduha uređaja može imati negativne efekte na biljke i životinje.
- Pazite da klima uređaj ne dođe u kontakt sa vodom. Može se oštetići električna izolacija i na taj način prouzrokovati strujni udar.
- Ne penjite se na spoljnu jedinicu i ne postavljajte nikakve predmete na nju.
- Nikada ne ubacujte štapiće ili slične predmete u uređaj. To može prouzrokovati povrede.
- Decu treba nadgledati kako bi se osiguralo da se ne igraju uređajem. Ako je kabl za napajanje oštećen, proizvođač, njegov serviser ili slično kvalifikovana osoba mora ga zameniti kako bi se izbegla opasnost.

IMENA DELOVA

UNUTRAŠNJA JEDINICA

Br.	Opis
1	Prednji panel
2	Vazdušni filter
3	Opcionalni filter (ukoliko je postavljen)
4	LED ekran
5	Prijemnik signala
6	Poklopac priključnog bloka
7	Generator ionizatora (ako je instaliran)
8	Deflektori
9	Dugme za hitne slučajeve
10	Nalepnica sa karakteristikama unutrašnje jedinice (položaj lepljenja po izboru)
11	Krilca za usmeravanje vazduha
12	Daljinski upravljač


UNUTRAŠNJA JEDINICA



SPOLJNA JEDINICA







Br.	Opis
13	Rešetka za izlaz vazduha
14	Nalepnica sa karakteristikama spoljne jedinice
15	Poklopac priključnog bloka
16	Ventil za gas
17	Ventil za tečnost

SPOLJNA JEDINICA



Napomena : Slike prikazane iznad imaju za cilj upoznavanje sa delovima uređaja i možda ne odgovaraju stvarnom izgledu uređaja koji ste kupili.

EKRAN UNUTRAŠNJE JEDINICE



Br.	Led		Funkcija
1	POWER	⊕	Ovaj simbol se pojavi kada je uređaj uključen.
2	SLEEP	☾	Režim spavanja
3	Prikaz temperature (Ako je prisutan) /Prikaz koda greške	88	(1) Svetli tokom rada tajmera, kada je klima uređaj uključen (2) Prikazuje kod greške kada dođe do kvara
4	TIMER	⌚	Svetli tokom rada tajmera.
5	RUN	❖	Simbol se pojavi kada je jedinica uključena i nestaje po isključenju jedinice.

⚠ Oblik i položaj tastera i indikatora mogu se razlikovati u zavisnosti od modela, ali njihova funkcija je ista.


FUNKCIJA U HITNIM SLUČAJEVIMA I FUNKCIJA AUTOMATSKOG RESTARTOVANJA UREĐAJA

FUNKCIJA AUTOMATSKOG RESTARTOVANJA

Ovaj uređaj je fabrički podešen da ima funkciju za automatsko restartovanje. U slučaju iznenadnog nestanka struje, uređaj pamti podešavanja pre nestanka struje; kada se napajanje strujom ponovo uspostavi, uređaj se automatski restartuje sa svim prethodnim podešavanjima.

Za deaktiviranje funkcije AUTOMATSKOG RESTARTOVANJA, uradite kao u nastavku:

1. Isključite klima uređaj ili ga isključite sa napajanja.
 2. Pritisnite dugme za hitne slučajeve i priključite uređaj na napajanje.
 3. Nastavite sa pritiskom dugmeta za hitne slučajeve više od 10 sekundi dok ne čujete kratak zvučni signal iz jedinice. Funkcija AUTOMATSKOG RESTARTOVANJA je deaktivirana.
- Za aktiviranje funkcije AUTOMATSKOG RESTARTOVANJA, sledite istu proceduru dok ne čujete tri kratka zvučna signala iz jedinice.




FUNKCIJA U HITNIM SLUČAJEVIMA

Ukoliko daljinski upravljač počne loše da radi ili je potrebna popravka, uradite sledeće:

Otvorite i podignite prednji panel nagore kako bi došli do dugmeta za hitne slučajeve.

1. Pritisnite dugme jednom (čuje se jedan zvučni signal) i uređaj će početi s radom u režimu HLAĐENJA.
2. Pritisnite dugme dva puta u roku od 3 sekunde (dva zvučna signala) i uređaj će početi s radom u režimu GREJANJA.
3. Da biste isključili uređaj, potrebno je da ponovo pritisnete ovo dugme (čuje se jedan duži zvučni signal).
4. Nakon 30 minuta rada, klima uređaj će automatski početi s radom u režimu hlađenja sa temperaturom od 23°C automatskom brzinom ventilatora.

* Funkcija FEEL opisana je na strani 15.



Dugme za hitne slučajeve kod nekih modela može biti na desnoj strani jedinice ispod prednjeg panela.

Oblik i položaj dugmeta za hitne slučajeve može se razlikovati u zavisnosti od modela, ali je njegova funkcija ista.

Napomena: spoljni statički pritisak topotnih pumpi je 0 Pa za sve modele.

IMENA DELOVA

RB.	TASTER	FUNKCIJA
1		Za uključivanje/isključivanje klima uređaja.
2		Za odabir režima rada: AUTOMATSKI, HLAĐENJE, SUŠENJE, VENTILACIJA, GREJANJE
3		Za ovećavanje podešene temperature u prostoriji ili produženje vremena kada je uključen TAJMER.
4		Za smanjivanje podešene temperature u prostoriji ili skraćenje vremena kada je uključen TAJMER.
5		Za podešavanje smera protoka vazduha gore i dole.
6		Za podešavanje smera protoka vazduha levo i desno (ako je primenjivo, opcionalo).
7		Za indikator opcionalnih funkcija: Čišćenje/ECO/Tajmer/Električno grejanje.
8		Za uključivanje/isključivanje ekrana unutrašnje jedinice.
9		Za odabir brzine ventilatora unutrašnje jedinice.
10		Za uključivanje/isključivanje funkcije I FEEL.
11		Za aktiviranje/deaktiviranje funkcije DEČIJA ZAŠTITA (CHILD-LOCK) istovremeno pritisnite i držite

Prikaz i neke funkcije daljinskog upravljača mogu se razlikovati u zavisnosti od modela.


Oblik i pozicija tastera i indikatora mogu se razlikovati u zavisnosti od modela, ali njihove funkcije ostaju iste.

Uredaj potvrđuje ispravno prihvatanje svakog tastera zvučnim signalom.

Čućete zvučni signal kada pritisnete taster , čak i ako taj model ne poseduje ovu funkciju.

Izvinjavamo se zbog neprijatnosti.

DALJINSKI UPRAVLJAČ



Čućete zvučni signal kada pritisnete taster  , iako stvarni model ne poseduje ovu funkciju.

Izvinjavamo se zbog neprijatnosti.

DALJINSKI UPRAVLJAČ

Ekran daljinskog upravljača
Značenje simbola na LCD ekranu.

RB.	SIMBOL	ZNAČENJE
1		Indikator signala
2		Čišćenje
3		Brzina ventilatora
4		Funkcija SLEEP
5		Tajmer
6		TURBO funkcija
7		Dečija zaštita (Child-Lock)
8		Električno grejanje
9		Automatski režim
10		Funkcija bez zvuka
11		Režim hlađenja
12		Uključivanje/isključivanje ekrana unutrašnje jedinice
13		Režim sušenja
14		Automatsko pomeranje levo-desno
15		Automatsko pomeranje gore-dole
16		ECO režim
17		Indikator temperature/vremena
18		Režim samo ventilacija
19		Režim grejanja
20		UV lampa
21		I FEEL funkcija
22		Funkcija bez zvuka sa najnižom brzinom ventilatora
23		Niska brzina ventilatora
24		Srednje-niska brzina ventilatora
25		Srednja brzina ventilatora
26		Srednje-visoka brzina ventilatora
27		Visoka brzina ventilatora
28		Automatska brzina ventilatora
29		TURBO funkcija sa najvećom brzinom ventilatora

DALJINSKI UPRAVLJAČ

ZAMENA BATERIJA


Skinite poklopac za baterije sa zadnje strane daljinskog upravljača tako što ćete ga pomeriti u pravcu strelice.

Umetnute baterije u skladu sa oznakama polariteta (+ i -) prikazanim na daljinskom upravljaču.

Ponovo postavite poklopac za baterije klizanjem na mesto.

⚠️ Koristite 2 LRO 3 AAA (1.5V) baterije. Nemojte koristiti punjive baterije. Zamenite stare baterije novim istog tipa kada ekran postane nečitljiv.

Ne odlažite baterije kao komunalni otpad. Prikupljanje ovog tipa otpada se mora vršiti odvojeno zbog specijalnog tretmana.




NAPOMENE:

1. Ako ne koristite daljinski upravljač duže vreme, izvadite baterije.
2. Istovremeno pritisnite i držite tastera \wedge i \vee duže od 1 sekunde da biste aktivirali funkciju dečije zaštite. Ponovo pritisnite dugmad da biste je deaktivirali.

Uklonite baterije kako biste izbegli oštećenja izazvana curenjem.




1. Usmerite daljinski upravljač prema unutrašnjoj jedinici klima uređaja.
2. Uverite se da između daljinskog upravljača i prijemnika signala na unutrašnjoj jedinici nema nikakvih prepreka.
3. Nikada ne ostavljajte daljinski upravljač izložen sunčevim zracima.
4. Držite daljinski upravljač na udaljenosti od najmanje 1 metar od televizora ili drugih električnih uređaja.



DALJINSKI UPRAVLJAČ

Vazduh koji ventilator usisava ulazi kroz rešetku prolazi kroz filter, zatim se hladi/odvlažuje ili greje kroz izmenjivač toplove.

Pravac protoka vazduha se može usmeriti gore i dole pomoću klapne i kontroliše se pomoću motora, dok se desno i levo može ručno podešiti pomoću vertikalnih deflektora. Kod nekih modela, vertikalni deflektori mogu biti kontrolisani pomoću motora.



Kontrolisanje pravca protoka vazduha


1. Za promenu pravca vertikalnog protoka vazduha:

Pritisnite da biste aktivirali horizontalne klapne za automatsko pomeranje gore-dole, simbol će se prikazati na ekranu daljinskog upravljača. Ponovo pritisnite taster da biste zaustavili pomeranje klapne i zadržali trenutni ugao protoka vazduha.

2. Za promenu pravca horizontalnog protoka vazduha:


Ručno promenite pravac vertikalnih deflektora kada se horizontalne klapne ne pomera. Pritisnite da biste omogućili pomeranje vertikalnih deflektora levo-desno. Ponovo pritisnite taster da zaustavite pomeranje vertikalnih deflektora i zadržite trenutni ugao protoka vazduha.

(Međutim, ukoliko kod ovog modela ova funkcija ne postoji, kada pritisnete ovaj taster, čuje se samo zvučni signal i na ekranu daljinskog upravljača se prikazuje simbol .



Nikada ručno ne podešavajte "Horizontalnu klapnu", jer se možda neće potpuno zatvoriti kada isključite klima uredaj.

Nikada ne stavljajte prste, štapove ili druge predmete u otvore za usisavanje ili izduvavanje vazduha. Takav slučajni kontakt sa pokretnim delovima može izazvati nepredvidivu štetu ili povrede.



DALJINSKI UPRAVLJAČ


REŽIM HLAĐENJA

COOL

Funkcija hlađenja omogućava klima uređaju da hlađi prostoriju i istovremeno smanjuje vlažnost vazduha.

Da biste aktivirali funkciju hlađenja (COOL), pritisnite taster  dok se simbol  ne pojavi na ekranu.

Pomoću tastera  ili  podešite temperaturu nižu od trenutne temperature u prostoriji.



REŽIM GREJANJA

HEAT

Funkcija hlađenja omogućava klima uređaju da hlađi prostoriju i  istovremeno smanjuje vlažnost vazduha.

Da biste aktivirali funkciju hlađenja (COOL), pritisnite taster  dok se simbol  ne pojavi na ekranu.

Pomoću tastera  ili  podešite temperaturu nižu od trenutne temperature u prostoriji.

 Tokom rada u režimu grejanja, uređaj može automatski aktivirati ciklus odmrzavanja (defrost), što je neophodno za uklanjanje leda sa kondenzatora kako bi se povratila njegova funkcija razmene toplote. Ovaj postupak obično traje 2-10 minuta. Tokom procesa odmrzavanja, ventilator unutrašnje jedinice prestaje sa radom. Nakon završetka procesa odmrzavanja, uređaj se automatski vraća u režim grejanja.

REŽIM SUŠENJA

DRY

Ova funkcija smanjuje vlažnost vazduha kako bi prostorija bila prijatnija.

Da biste aktivirali funkciju sušenja (DRY), pritisnite  dok se simbol  ne pojavi na ekranu.

Automatski će se aktivirati funkcija sa unapred podešenim parametrima.


DALJINSKI UPRAVLJAČ

REŽIM VENTILACIJE (nije taster ventilatora)

FAN 

Režim ventilacije, samo ventilacija vazduha.

Da biste aktivirali funkciju ventilacije (FAN), pritisnite dugme  dok se simbol  ne pojavi na ekranu. Automatski će se aktivirati funkcija sa unapred podešenim parametrima.




AUTOMATSKI REŽIM

AUTO 

Režim ventilacije, samo ventilacija vazduha.

Da biste aktivirali funkciju ventilacije (FAN), pritisnite dugme  dok se simbol  ne pojavi na ekranu. Automatski će se aktivirati funkcija sa unapred podešenim parametrima.



FUNKCIJA EKRANA (ekran unutrašnje jedinice)

DISPLAY

Uključivanje/isključivanje LED ekrana na unutrašnjoj jedinici. Pritisnite taster  da biste isključili LED ecran unutrašnje jedinice. Ponovo pritisnite taster da biste uključili LED ekan unutrašnje jedinice.

DALJINSKI UPRAVLJAČ


ECO funkcija

 **ECO** Ova funkcija omogućava uređaju da automatski postavi radni režim kako bi uštedeo energiju.

Samo u režimu grejanja ili hlađenja, pritisnite taster  odaberite ECO pritiskom tastera  ili  dok se simbol ECO ne pojavi na ekranu unutrašnje jedinice. Nakon toga pritisnite taster  ponovo i uređaj će pokrenuti ECO režim.

NAPOMENA:

ECO funkcija je dostupna u oba režima, HLADNJENJE i GREJANJE.



SLEEP Funkcija

 SLEEP

Unapred podešen automatski operativni program.

Pritisnite taster , zatim pritisnite taster  i  dok  simbol ne počne da treperi, a potom pritisnite  da potvrdite izbor i aktivirate SLEEP funkciju.

Ponovite isti postupak da biste zaustavili ovu funkciju.

NAPOMENA:

SLEEP funkcija je dostupna u oba režima, HLADNJENJE i GREJANJE.

Nakon 10 sati rada u SLEEP režimu, klima uređaj će se vratiti na prethodno podešeni režim.

DALJINSKI UPRAVLJAČ

Funkcija samostalnog čišćenja (opciono)




Tokom procesa, na unutrašnjem displeju prikazuje se "AC". Isključite klima uređaj pritiskom tastera . Pritiskom tastera , simbol će početi da treperi. Ponovo pritisnite da biste aktivirali funkciju ČIŠĆENJA, a na ekranu unutrašnje jedinice će se pojaviti AC. Pritisnite isti taster ponovo da biste deaktivirali ovu funkciju.

NAPOMENA:

- Preporučujemo da koristite ovu funkciju u sledećim uslovima kako biste izbegli aktivaciju sigurnosnih zaštitnih mehanizama:

Unutrašnja jedinica	Temperatura < 30°C
Spoljašnja jedinica	5°C < Temperatura < 30°C

- Preporučujemo da ovu funkciju koristite na svaka 3 meseca.




Kontrola brzine ventilatora

Izaberite brzinu ventilatora u sledećim režimima AUTOMATSKI/VENTILACIJA/HLAĐENJE/ GREJANJE.

Pritisnite taster da biste podešili brzinu ventilatora: AUTOMATSKI/NEČUJNO/NISKA BRZINA/SREDNJE-NISKA BRZINA/SREDNJA BRZINA/SREDNJE-VISOKA BRZINA/VISOKA BRZINA/TURBO BRZINA.

	Nečujno uz najnižu brzinu ventilatora
	Niska brzina ventilatora
	Srednje-niska brzina ventilatora
	Srednja brzina ventilatora
	Srednje-visoka brzina ventilatora
	Visoka brzina ventilatora
	Automatska brzina ventilatora
	Turbo uz najvišu brzinu ventilatora



DALJINSKI UPRAVLJAČ


TAJMER funkcija

► TIMER

Omogućava automatsko uključivanje/isključivanje
klima uređaja

Kada je uređaj isključen, možete podesiti TIMER ON za automatsko uključivanje:

1. Pritisnite taster  , izaberite  pritiskom tastera  ili  dok se simbol  ne pojavi na ekranu unutrašnje jedinice. Zatim pritisnite taster  ponovo.
2. Podesite željeni režim rada/brzinu ventilatora/temperaturu, zatim ponovo pritisnite taster .
3. Na ekranu unutrašnje jedinice će treptati digitalni prikaz, na primer 0.5H, pritisnite  ili  da biste podesili željeno vreme isključivanja u intervalu od 0.5h do 24h. Potom pritisnite taster  da potvrdite odabir.
4. Isključite ovu funkciju pritiskom tastera  .



Kada je uređaj uključen, možete podesiti TIMER OFF za automatsko isključivanje:

1. Pritisnite taster  , izaberite  pritiskom tastera  ili  dok se simbol  ne pojavi na ekranu unutrašnje jedinice. Zatim pritisnite taster ponovo.
2. Pritisnite  ili  da podesite željeno vreme automatskog uključivanja u intervalu od 0.5h do 24h. Potom pritisnite taster da  potvrdite odabir.
3. Isključite ovu funkciju pritiskom tastera  .

Za otakzivanje TAJMER funkcije pritisnite taster TIMER dva puta zaredom.



Napomena:


Sve postavke treba izvršiti u roku od 5 sekundi, inače će podešavanje biti otkazano.

Funkcija I FEEL (Opcionalno)

I FEEL

Pritisnite taster **I FEEL** da biste aktivirali funkciju, simbol  će se pojaviti na ekranu daljinskog upravljača.
Ponovo pritisnite isti taster da biste deaktivirali ovu funkciju.

Ova funkcija omogućava daljinskom upravljaču da meri temperaturu na trenutnoj lokaciji na kojoj se nalazi i šalje signal klima uređaju kako bi optimizovao temperaturu oko vas i pružio najveći komfor.
Ova funkcija će se automatski deaktivirati nakon 2 sata rada.



ZAŠTITA

Klima uređaj je programiran da obezbedi ugodne životne uslove. Ako se koristi u neprikladnim klimatskim uslovima, kao što je prikazano u nastavku, mogu se aktivirati određene zaštitne funkcije.

Za modele u T1 klimatskim uslovima:

Br.	REŽIM	Temperatura okoline
1	Grejanje	Spoljna temperatura je preko 24°C
		Spoljna temperatura je ispod -7 °C
		Sobna temperatura je preko 27 °C
2	Hlađenje	Spoljna temperatura je preko 43°C
		Sobna temperatura je preko 21°C
3	Isušivanje	Sobna temperatura je ispod 18 °C

Za modele u tropskim (T3) klimatskim uslovima:

Br.	REŽIM	Temperatura okoline
1	Grejanje	Spoljna temperatura je preko 24°C
		Spoljna temperatura je ispod -7 °C
		Sobna temperatura je iznad 27 °C
2	Hlađenje	Spoljna temperatura je preko 52°C
		Sobna temperatura je ispod 21 °C
3	Isušivanje	Sobna temperatura je ispod 18 °C


 Uredaj ne radi odmah ako je uključen nakon isključivanja ili nakon promene režima tokom rada. Ovo je normalna akcija samozaštite, treba sačekati oko 3 minuta.

 Kapacitet i efikasnost dati su prema ispitivanju sprovedenom pri punom opterećenju *. * Potrebna je najveća brzina motora unutrašnjeg ventilatora i maksimalni otvoreni ugao krilaca i deflektora.

PRIRUČNIK ZA INSTALACIJU --- Izbor mesta instalacije

UNUTRAŠNJA JEDINICA


- Postavite unutrašnju jedinicu na čvrst zid koji nije izložen vibracijama.
- Otvori za ulaz i izlaz vazduha ne smeju biti ometani: vazduh treba da duva po celoj sobi.
- Ne postavljajte jedinicu u blizini izvora toplice, pare ili zapaljivog gasa.
- Instalirajte jedinicu u blizini električne utičnice ili strujnog kola.
- Ne postavljajte jedinicu tamo gde će biti izložena direktnoj sunčevoj svetlosti.
- Izaberite mesto gde se kondenzovana voda može lako isprazniti i gde se lako može povezati sa spoljnom jedinicom.
- Redovno proveravajte rad uređaja i obezbedite potreban prostor kao što je prikazano na slici.
- Izaberite mesto postavljanja gde se filter može lako izvaditi.




SPOLJNA JEDINICA

- Ne postavljajte spoljnju jedinicu u blizini izvora toplice, pare ili zapaljivog gasa.
- Ne postavljajte jedinicu na previše vetrovitim ili prašnjavim mestima.
- Ne postavljajte jedinicu tamo gde ljudi često prolaze. Izaberite mesto gde ispuštanje vazduha i radni zvuk neće smetati komšijama.
- Izbegavajte postavljanje jedinice tamo gde će biti izložena direktnoj sunčevoj svetlosti (ako je potrebno, koristite zaštitu koja ne sme ometati protok vazduha).
- Obezbedite prostor kao što je prikazano na slici da bi vazduh mogao slobodno da cirkuliše.
- Postavite spoljnju jedinicu na sigurno i čvrsto mesto.
- Ako je spoljna jedinica izložena vibracijama, postavite gumene poklopce na nogare jedinice.

minimalni prostor koji treba obezbediti (mm) prikazan na slici



Šema instalacije



Kupac se mora uveriti da osoba i / ili kompanija koja treba da instalira, održava ili popravlja ovaj klima uređaj ima kvalifikacije i iskustvo u proizvodima sa rashladnim sredstvima.

PRIRUČNIK ZA INSTALACIJU --- Instaliranje unutrašnje jedinice

Pre početka ugradnje, odlučite o položaju unutrašnje i spoljašnje jedinice, uzimajući u obzir minimalni prostor koji treba obezbediti oko jedinica.


⚠ Ne instalirajte klima uredaj u vlažnu prostoriju, kao što je kupatilo ili vešernica, itd.

⚠ Mesto ugradnje treba da bude 250 cm ili više iznad poda.

Da biste instalirali, postupite na sledeći način:

Postavljanje montažne ploče

- 1 Uvek montirajte zadnju ploču horizontalno i vertikalno
- 2 Izbušite 32 mm duboke rupe u zidu da biste pričvrstili ploču;
3. Umetnite plastična sidra u rupu;
4. Počvrstite zadnju ploču na zid pomoću predviđenih vijaka
- 5.Uverite se da je zadnja ploča fiksirana dovoljno čvrsto da izdrži težinu




Napomena: Oblik montažne ploče može se razlikovati od prikazanog na slici, ali je način ugradnje isti.

Bušenje rupe u zidu za cevovode

1. Napravite otvor za cevovod ($\Phi 55$) u zidu pod blagim nagibom prema dole na spoljnoj strani.
2. Umetnите čahuru otvora za cevovod u rupu da biste sprečili oštećenje cevovoda za povezivanje i ožičenje prilikom prolaska kroz rupu.

⚠ Rupa se mora nagnijati nadole na spoljnoj strani

Napomena: Odvodnu cev držite nadole prema pravcu zidne rupe, u suprotnom može doći do curenja.



Električno povezivanje --- Unutrašnja jedinica

1. Otvorite prednju ploču.
2. Skinite poklopac kako je naznačeno na slici (uklanjanjem vijka ili izvlačenjem iz kukica).
3. Za električno povezivanje pogledajte šemu kola na desnom delu jedinice ispod prednje ploče.
4. Povežite kablovске žice sa stezalkama zavrtnja sledeći numeraciju. Koristite veličinu žice prikladnu za ulaznu snagu (vidi natpisnu pločicu na uređaju) i prema svim važećim nacionalnim sigurnosnim zahtevima.


⚠ Kabl koji povezuje spoljnu i unutrašnju jedinicu mora biti pogodan za spoljnu upotrebu.

⚠ Utikač mora biti dostupan i nakon instaliranja uređaja tako da se može izvući ako je potrebno.

⚠ Mora se osigurati efikasno uzemljenje.

⚠ Ako je kabl za napajanje oštećen, mora ga zameniti ovlašćeni servisni centar.

Napomena: Proizvođač, kod modela bez priključnih blokova, žice može da poveže na glavni PCB unutrašnje jedinice.





PRIRUČNIK ZA INSTALACIJU --- Instaliranje unutrašnje jedinice

Priklučak cevovoda sa rashladnim sredstvom


Cevovodi se mogu izvoditi u 3 smera označena brojevima na slici. Kad se cevovod izvodi u smeru 1 ili 3, zarežite udubljenje duž žleba na bočnoj strani unutrašnje jedinice.

Izvedite cevovod u smeru zidne rupe i povežite bakarne cevi, odvodnu cev i kablove za napajanje zajedno sa trakom sa odvodnim crevom na dnu, tako da voda može slobodno da teče.


- Ne skidajte poklopac sa cevi dok je ne povežete kako biste izbegli ulazak vlage ili prljavštine.
- Ako je cev savijena ili prečesto vučena, postaće kruta. Ne savijajte cev više od tri puta u jednom trenutku.
- Kada produžavate urolano crevo, ispravite crevo lagano ga odmotavajući kao što je prikazano na slici.




Obmotajte priključnu cev




Proširenje urolanog creva



moment ključ



DA



Povezivanje na unutrašnju jedinicu

1. Uklonite poklopac cevi unutrašnje jedinice (proverite da li unutra ima nečistoća).
2. Umetnite maticu i napravite prirubnicu na kraju priključne cevi.
3. Pritegnite veze pomoću dva ključa koji rade u suprotnim smerovima.

Odvod kondenzovane vode iz unutrašnje jedinice

Odvod kondenzovane vode iz unutrašnje jedinice je osnovni za uspeh instalacije.


1. Postavite odvodno crevo ispod cevovoda, pazејi da ne napravite sifone.
 2. Crevo za odvod mora biti nagnuto nadole kako bi pomoglo oticanju vode.
 3. Ne savijajte odvodno crevo niti ga ostavljajte izbočeno ili uvijeno i ne stavljamte kraj u vodu. Ako je produžetak povezan sa odvodnim crevom, uverite se da ga ostaje još kada pređe u unutrašnju jedinicu.
 4. Ako su cevovodi postavljeni udesno, cevi, napojni kabl i odvodno crevo moraju biti pričvršćeni na zadnji deo jedinice cevnim priključkom.
- 1) Utaknite cevni priključak u odgovarajući otvor.
 - 2) Pritisnite da spojite cevni priključak sa bazom.

PRIRUČNIK ZA INSTALACIJU --- Instaliranje unutrašnje jedinice

INSTALACIJA UNUTRAŠNJE JEDINICE

Nakon spajanja cevi u skladu sa uputstvima, ugradite priključne kablove. Onda postavite odvodno crevo. Nakon spajanja obmotajte cevi, kablove i odvodno crevo izolacionim materijalom.

1. Dobro raspoređite cevi, kablove i odvodno crevo.
2. Obmotajte spojeve cevi izolacionim materijalom, pričvršćujući ih vinil trakom.
3. Provucite priključnu cev, kablove i odvodno crevo kroz zidnu rupu i čvrsto postavite unutrašnju jedinicu na gornji deo montažne ploče.
4. Pritisnite čvrsto donji deo unutrašnje jedinice prema montažnoj ploči.



PRIRUČNIK ZA INSTALACIJU --- Instaliranje spoljne jedinice


- Spojlju jedinicu treba postaviti na čvrsti zid i dobro pričvrstiti.
- Pre povezivanja cevi i kablova za povezivanje mora se poštovati sledeći postupak: odlučite koji je najbolji položaj na zidu i ostavite dovoljno prostora da se lako izvrši održavanje.
- Pričvrstite nosač na zid pomoću sidrenih vijaka koji su posebno prilagođeni tipu zida;
- Koristite veću količinu sidrenih vijaka od one koja je uobičajena za težinu koju moraju da podnesu da bi se izbegle vibracije tokom rada i ostale pričvršćene u istom položaju godinama, a da vijci ne olabave.
- Uredaj mora biti instaliran u skladu sa nacionalnim propisima.

Odvod kondenzovane vode iz spoljne jedinice (samo za modele sa toplotnom pumpom)

Kondenzovana voda i led koji se stvaraju u spoljnoj jedinici tokom grejanja mogu oticati kroz odvodno crevo

1. Pričvrstite otvor za odvod u rupu od 25 mm postavljenu u delu jedinice kao što je prikazano na slici.
2. Povežite odvodni otvor i odvodno crevo.


Obratite pažnju da voda otiče na odgovarajućem mestu.



PRIRUČNIK ZA INSTALACIJU --- Instaliranje spoljne jedinice

ELEKTRIČNO POVEZIVANJE

1. Uklonite ručicu sa desne bočne ploče spoljne jedinice.
2. Priklučite kabl za napajanje na priključnu ploču.
- Ožičenje treba da odgovara kablu unutrašnje jedinice.
3. Pričvrstite kabl za napajanje žičanom stezaljkom.
4. Potvrdite da li je žica pravilno fiksirana.
5. Mora se osigurati efikasno uzemljenje.
6. Vratite dršku.




POVEZIVANJE CEVI

Zavrnite matice navrtke na spojnicu spoljne jedinice istim postupcima zatezanja opisanim kod unutrašnje jedinice.


Da biste izbegli curenje, obratite pažnju na sledeće:

1. Pritisnite navrtke pomoću dva ključa. Obratite pažnju da ne oštetite cevi.
2. Ako obrtni momenat zatezanja nije dovoljan, verovatno će doći do curenja. Sa prekomernim obrtnim momentom zatezanja takođe će doći do curenja, jer bi prirubnica mogla biti oštećena.
3. Najsigurniji sistem sastoji se u zatezivanju veze pomoću fiksнog ključa i moment ključa: u ovom slučaju koristite tabelu na strani 23.



ISUŠIVANJE

Vazduh i vlagu koji ostaju u krugu rashladnog sredstva mogu prouzrokovati kvar na kompresoru. Nakon povezivanja unutrašnje i spoljne jedinice, isušite vazduh i vlagu iz kruga rashladnog sredstva pomoću vakuum pumpe.





PRIRUČNIK ZA INSTALACIJU --- Instaliranje spoljne jedinice

ISUŠIVANJE

Vazduh i vlagu koji ostaju u krugu rashladnog sredstva mogu prouzrokovati kvar na kompresoru. Nakon povezivanja unutrašnje i spoljne jedinice, isušite vazduh i vlagu iz kruga rashladnog sredstva pomoću vakuum pumpa.

- (1) Odvrnite i uklonite poklopce sa dvokrakih trokrakih ventila.
- (2) Odvijte i uklonite poklopac sa servisnog priključka.
- (3) Spojite crevo vakuumske pumpe na servisni priključak.
- (4) Vakuum pumpom upravlajte 10 - 15 minuta dok se ne postigne apsolutni vakuum od 10 mm Hg.
- (5) Dok je vakuumska pumpa još uvek u radu, zatvorite dugme niskog pritiska na spojnici vakuumske pumpe. Zaustavite vakuumsku pumpu.
- (6) Otvorite dvokraki ventil za 1/4 okreta, a zatim ga zatvorite nakon 10 sekundi. Proverite da li svi spojevi propuštaju tečnim sapunom ili elektronskim uređajem za curenje.
- (7) Okrenite telo dvokrakih i trokrakih ventila. Odvojite crevo vakuumske pumpe.
- (8) Vratite i zategnjite sve poklopce na ventilima.

Šema trokrakog ventila



PRIRUČNIK ZA INSTALACIJU --- Testiranje

1. Vetroizolacioni poklopac oko spojeva unutrašnje jedinice i pričvrstite ga izolacijskom trakom.
2. Pričvrstite višak dela signalnog kabla na cevovod ili na spoljnu jedinicu.
3. Pričvrstite cevovod na zid (nakon što ste ga obmotali izolacionom trakom) pomoću stezaljki ili ih umetnите u plastične proreze.
4. Zatvorite otvor na zidu kroz koji prolaze cevovodi tako da vazduh ili voda ne mogu da prođu.


Testiranje unutrašnje jedinice

- Da li ON / OFF i VENTILATOR rade normalno?
- Da li MODE radi normalno?
- Da li tasteri za postavke i TIMER pravilno funkcionišu?
- Da li svaka lampica normalno svetli?
- Da li krilca za smer protoka vazduha rade normalno?
- Da li kondenzovana voda redovno otiče?

Testiranje spoljne jedinice

- Da li postoji neuobičajena buka ili vibracija tokom rada?
- Da li bi buka, protok vazduha ili odvod kondenzovane vode mogli da uzinemire komšije?
- Postoji li curenje rashladne tečnosti?

Napomena: elektronski kontroler omogućava kompresoru da se pokrene samo tri minute nakon što sistem dostigne napon.



PRIRUČNIK ZA INSTALACIJU --- Informacije za instalatera

TIP FIKSNE BRZINE MODEL kapacitet (Btu/h)	5k	7k	9k	12k	15/18k	22/24k	28/30k/36k
Prečnik cevi za tečnost	1/4 " (φ6)	1/4 " (φ6)	1/4 " (φ6)	1/4 " (φ6)	1/4 " (φ6)	3/8 " (φ9,52)	3/8 " (φ9,52)
Prečnik cevi za gas	3/8 " (φ9,52)	3/8 " (φ9,52)	3/8 " (φ9,52)	1/2 " (φ12)	1/2 " (φ12)	5/8 " (φ15,88)	5/8 " (φ15,88)
Dužina cevi sa standardnim punjenjem	3m	3m	3m	3m	4m	4m	4m
Maksimalna udaljenost između unutrašnje i spoljne jedinice	15m	15m	15m	15m	15m	15m	15m
Dodatno punjenje rashladnog sredstva	20g/m	20g/m	20g/m	20g/m	30g/m	30g/m	30g/m
Maks. razl. u nivou između unutrašnje i spoljne jedinice	5m	5m	5m	5m	5m	5m	5m
Tip rashladnog sredstva (1)	R22	R22	R22	R22	R22	R22	R22

TIP FIKSNE BRZINE MODEL kapacitet (Btu/h)	7k	9k	12k	15/18k	22/24k	28/30k/36k
Prečnik cevi za tečnost	1/4 " (φ6)	1/4 " (φ6)	1/4 " (φ6)	1/4 " (φ6)	3/8 " (φ9,52)	3/8 " (φ9,52)
Prečnik cevi za gas	3/8 " (φ9,52)	3/8 " (φ9,52)	3/8 " (φ9,52)	1/2 " (φ12)	5/8 " (φ15,88)	5/8 " (φ15,88)
Dužina cevi sa standardnim punjenjem	3m	3m	3m	4m	4m	4m
Maksimalna udaljenost između unutrašnje i spoljne jedinice	15m	15m	15m	15m	15m	15m
Dodatno punjenje rashladnog sredstva	20g/m	20g/m	20g/m	30g/m	30g/m	30g/m
Maks. razl. u nivou između unutrašnje i spoljne jedinice	5m	5m	5m	5m	5m	5m
Tip rashladnog sredstva (1)	R410A	R410A	R410A	R410A	R410A	R410A

INVERTERSKI TIP MODEL kapacitet (Btu/h)	9k	12k	15/18k	22/24k
Prečnik cevi za tečnost	1/4 " (φ6)	1/4 " (φ6)	1/4 " (φ6)	3/8 " (φ9,52)
Prečnik cevi za gas	3/8 " (φ9,52)	3/8 " (φ9,52)	1/2 " (φ12)	5/8 " (φ15,88)
Dužina cevi sa standardnim punjenjem	3m	3m	3m	4m
Maksimalna udaljenost između unutrašnje i spoljne jedinice	15m	15m	15m	15m
Dodatno punjenje rashladnog sredstva	20g/m	20g/m	20g/m	30g/m
Maks. razl. u nivou između unutrašnje i spoljne jedinice	5m	5m	5m	5m
Tip rashladnog sredstva (1)	R410A	R410A	R410A	R410A

(1) Pogledajte nalepnici sa podacima zapepljenu na spoljnoj jedinici.

MOMENT PRITEZANJA ZA ZAŠTITU KRILACA I POVEZIVANJE ZAVRTNJA

CEV	MOMENT PRITEZANJA [N x m]	ODGOVARAJUĆI PRITISAK (pomoću ključa od 20 cm)		MOMENT PRITEZANJA [N x m]
1/4 " (φ6)	15 - 20	snaga zglobo	Navrtka za servisni priključak	7 - 9
3/8 " (φ9,52)	31 - 35	snaga ruke	Zaštitne kape	25 - 30
1/2 " (φ12)	35 - 45	snaga ruke		
5/8 " (φ15,88)	75 - 80	snaga ruke		



PRIRUČNIK ZA INSTALACIJU --- Informacije za instalatera

ŠEMA OŽIČENJA

Za različite modele, šema ožičenja može se razlikovati. Pogledajte šemu ožičenja zapepljenu na unutrašnjoj i spoljašnjoj jedinici Vašeg uređaja.

Na unutrašnjoj jedinici, šema ožičenja je zapepljena ispod prednje ploče;

Na spoljnoj jedinici, šema ožičenja je zapepljena na zadnjoj strani poklopca ručke spoljne jedinice.



Napomena: Za neke modele bez priključnog bloka proizvođač je spojio žice na glavni PCB unutrašnje jedinice.

PRIRUČNIK ZA INSTALACIJU --- Informacije za instalatera

SPECIFIKACIJA KABLOVSKIH ŽICA

MODEL	kapacitet (Btu/h)	5k	7k	9k	12k	15/18k	22/24k	28/30k/36k
		površina preseka						
Napojni kabl	N	1.0mm ² AWG18	1.0mm ² AWG18	1.0mm ² AWG18	1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.5mm ² AWG16	2.5mm ² AWG14 H05RN-F	4.0mm ² AWG12
	L	1.0mm ² AWG18	1.0mm ² AWG18	1.0mm ² AWG18	1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.5mm ² AWG16	2.5mm ² AWG14 H05RN-F	4.0mm ² AWG12
	E	1.0mm ² AWG18	1.0mm ² AWG18	1.0mm ² AWG18	1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.5mm ² AWG16	2.5mm ² AWG14 H05RN-F	4.0mm ² AWG12
Priključni kabl za napajanje	N	1.0mm ²	1.0mm ²	1.0mm ²	1.0mm ² (1.5mm) ³	1.5mm ²	0.75mm ²	0.75mm ²
	L	1.0mm ²	1.0mm ²	1.0mm ²	1.0mm ² (1.5mm) ³	1.5mm ²	0.75mm ²	0.75mm ²
	1	1.0mm ²	1.0mm ²	1.0mm ²	1.0mm ² (1.5mm) ³	1.5mm ²	0.75mm ²	0.75mm ²
	2	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²
	3	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²
	⊕	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²	0.75mm ²

INVERTERSKI TIP	MODEL	kapacitet (Btu/h)			9k	12k	18/22k	24k	
			površina preseka						
Napojni kabl	N			1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.5mm ² AWG16	2.5mm ² AWG14		
	L			1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.5mm ² AWG16	2.5mm ² AWG14		
	E			1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.0mm ² (1.5mm) ³ AWG18 (AWG16)	1.5mm ² AWG16	2.5mm ² AWG14		
Priključni kabl za napajanje	N			1.0mm ² (1.5mm) ³	1.0mm ² (1.5mm) ³	1.5mm ²	0.75mm ²		
	L			1.0mm ² (1.5mm) ³	1.0mm ² (1.5mm) ³	1.5mm ²	0.75mm ²		
	1			1.0mm ² (1.5mm) ³	1.0mm ² (1.5mm) ³	1.5mm ²	0.75mm ²		
	⊕			1.0mm ² (1.5mm) ³	1.0mm ² (1.5mm) ³	1.5mm ²	0.75mm ²		

220V 7K , 9K , 12K 15K , 16K , 18K , 22K , 24K , 30K parametar osigurača unutrašnje jedinice klima uređaja je 50T, 3.15A

110V 7K , 9K 12k parametar osigurača unutrašnje jedinice klima uređaja je 50T, 3.15A,

125V 7K , 9K , 12K parametar osigurača spoljne jedinice klima uređaja je 61T, 15A

250V 18K , 22K , 24K parametar osigurača spoljne jedinice klima uređaja je 65TS, 25A

ODRŽAVANJE



Periodično održavanje je neophodno za efikasnost vašeg klima uređaja.

Pre bilo kakvog održavanja, isključite napajanje izvlačenjem utikača iz utičnice.


UNUTRAŠNJA JEDINICA

FILTERI PROTIV SKUPLJANJA PRAŠINE

1. Otvorite prednju ploču prateći smer strelice.
2. Držite prednju ploču podignutu jednom rukom, a drugom rukom izvadite vazdušni filter.
3. Očistite filter vodom; ako je filter zaprljan uljem, može se oprati topлом vodom (ne toplijom od 45 °C). Ostaviti da se osuši na hladnom i suvom mestu.
4. Držeći prednju ploču jednom rukom, drugom rukom postavite filter za vazduh.
5. Zatvorite prednju ploču.



filter protiv skupljanja prašine



Elektrostaticki filter i filter za dezodorans (ako su instalirani) ne mogu se oprati ili obnoviti i moraju se zameniti novim filterima nakon svakih 6 meseci.

ČIŠĆENJE IZMENJIVAČA TOPLOTE

1. Otvorite prednju ploču jedinice i podignite je do najvećeg ugla, a zatim je otkačite sa šarki da biste olakšali čišćenje.
2. Očistite unutrašnju jedinicu krpom sa vodom (ne toplijom od 40 °C) i neutralnim sapunom. Nikada ne koristite agresivne rastvarače ili deterdžente.
3. Ako je spoljašnja jedinica začepljena, uklonite ostatke i otpad i uklonite prašinu mlazom vazduha ili sa malo vode.

ODRŽAVANJE NA KRAJU SEZONE

1. Isključite utikač ili automatski prekidač.
2. Očistite i zamenite filtere.
3. Po sunčanom danu pustite da klima uređaj radi u režimu ventilatora nekoliko sati, kako bi se unutrašnjost jedinice u potpunosti osušila.

ZAMENA BATERIJA

Kada:

- Nema potvrde zvučnim signalom iz unutrašnje jedinice.
- LCD ekran ne reaguje.

Kako:

- Skinite poklopac na pozadini uređaja.
- Postavite nove baterije vodeći računa o polovima + i -.

PAŽNJA: Koristite samo nove baterije. Izvadite baterije iz daljinskog upravljača kada klima uređaj nije u upotrebi.

UPOZORENJE ! Ne bacajte baterije u kontejnere za običan kućni otpad, treba ih odložiti u posebne kontejnere koji se nalaze na sabirnim mestima.

REŠENJA PROBLEMA

KVAR	MOGUĆI UZROCI
Uredaj ne radi	Prekid napajanja / izvučen utikač.
	Oštećen motor ventilatora unutrašnje / spoljne jedinice.
	Neispravan termomagnetski prekidač kompresora.
	Neispravan zaštitni uredaj ili osigurači.
	Otpušteni priključci ili utikači izvučeni.
	Ponekad prestane da radi kako bi zaštitio uredaj.
	Napon veći ili niži od raspona napona.
Čudan miris	Aktivirana je funkcija tajmera (TIMER-ON).
Zvuk tekuće vode	Oštećena elektronska kontrolna ploča.
Fina izmaglica dolazi iz otvora za vazduh	Prljav vazdušni filter.
Čuje se neobična buka	Povratni protok tečnosti u cirkulaciji rashladnog sredstva.
Nedovoljan protok vazduha, bilo vrućeg, bilo hladnog	To se dešava kada vazduh u sobi postane veoma hladan, na primer u režimima "HLAĐENJE" ili "ODVLAŽIVANJE / ISUŠIVANJE."
	Ova buka nastaje širenjem ili skupljanjem prednje ploče zbog promena temperature i ne ukazuje na problem.
	Neprikladno podešavanje temperature.
	Prepreke za usisavanje i izlaz vazduha klima uredaja.
	Prljav vazdušni filter.
Uredaj ne reaguje na komande	Brzina ventilatora postavljena na minimum.
	Ostali izvori toplote u sobi.
	Nema rashladnog sredstva.
	Daljinski upravljač nije dovoljno blizu unutrašnje jedinice.
Ekran je isključen	Potrebno je zameniti baterije daljinskog upravljača.
	Prepreke između daljinskog i prijemnika signala u unutrašnjoj jedinici.
Aktivna je LED funkcija	Aktivna je LED funkcija
	Nestanak struje

Odmah isključite klima uredaj i isključite napajanje u sledećim slučajevima:

- Čudni zvukovi tokom rada.
- Neispravna elektronska kontrolna ploča
- Neispravni osigurači ili prekidači.
- Prskanje vode ili predmeta unutar uređaja.
- Pregrejani kablovi ili utikači.
- Vrlo jaki mirisi koji dolaze iz uređaja.

SIGNALNE GREŠKE NA EKRANU

U slučaju greške, na ekranu unutrašnje jedinice prikazani su sledeći kodovi grešaka:

	Rad lampice	Opis problema
E1	trepti jednom	Kvar senzora unutrašnje temperature
E2	trepti dva puta	Kvar unutrašnjeg senzora temperature cevi
E6	trepti 6 puta	Neispravnost motora unutrašnjeg ventilatora.



Više o tehničkim karakteristikama ovog klima uređaja kao i o ostalim FOX Electronics proizvodima možete sazнати на internet adresi:

www.foxelectronics.rs